

TABLE OF CONTENTS

1. Purpose	2
2. Tools & Supplies	2
3. Procedure: Lower Hinge Replacement	2
3.1. Step 1	2
3.2. Step 2	3
3.3. Step 3	3
3.4. Step 4	4
3.5. Step 5	4
3.6. Step 6	5
3.7. Step 7	6

1. PURPOSE

This document describes the process required to replace the Lower Hinge on Nova Carts.

2. TOOLS & SUPPLIES

Flat blade screwdriver

T25 Torx security L Key



3. PROCEDURE: LOWER HINGE REPLACEMENT

3.1. STEP 1

Remove channel cover from extrusion near the hinge.



3.2. STEP 2

Remove the screw holding the arm using the T25 L Key.



3.3. STEP 3

Remove the arm and OmniTab bracket from the Lower hinge.



3.4. STEP 4

Remove the screw holding the lower hinge to the pole and then remove the hinge.



3.5. STEP 5

Place new hinge on the pole and engage the screw to hold it in place. Tight the screw firmly with the T25 L key until the hinge is flush with the adapter plate.



3.6. STEP 6

Place the arm back on the new hinge and engage the screw to hold it in place. Tight the screw firmly with the T25 L key until the hinge is flush with the adapter plate.



3.7. STEP 7

Put the channel cover strips removed at Step 1 back to the arm and pole where they came from.



End of Procedure